



How to Update the Thesycon Stack to Version 1.29.2

1. Open the zip file: T1394bus_v1.29.2_full.zip




2. Run the Thesycon Installer by double-clicking on: T1394bus_v1.29.2_full


3. The Thesycon Installer should open up. **Click Next.**



4. Select the path which you want to install the Thesycon Driver to. By default, it will install to: C:\Thesycon\T1394bus\v1.29.2\
Click Install.



5. The program will install all required files. Click **Next** and then click **Finish**.




6. Using Windows Explorer, navigate to: C:\Thesycon\T1394bus\v1.29.2\
Here you will see a variety of folders.

Open the folder: drv.install

This folder will contain everything you need to install the new Thesycon 1394 stack.


Within \drv.install\ you will see 2 folders: 32bit and 64bit

Open the folder corresponding to the appropriate bit-depth




7. After opening the folder (32bit in this example) you will see a list of files.

Double Click on: t1394bus_installwizard



8. The Thesycon driver setup wizard should open up. It should display all the 1394 controllers present on the device. By clicking on/selecting this driver, you are shown the host controller details and driver details below it.

After you have selected the 1394 controller, Click on: “Switch to T1394bus Driver” to install the Thesycon stack.



9. A dialog box should pop up notifying you of the installation. Click: "Continue Anyway."



10. Once the installation is done, selecting the Firewire controller information will display the T1394bus information.

Make sure that the version number displayed in "Driver details" is 1.29.2

